

# IMPORTANT SAFEGUARDS FOR MIXING AND KNEADING BOWLS

In addition to the GENERAL SAFEGUARDS in the front of this book, the following SAFEGUARDS should be followed:


1. Read all instructions.
2. Avoid contacting moving parts. Keep hands, hair, clothing, as well as spatulas and other utensils away from beaters during operation to prevent injury, and/or damage to the mixer.
3. Remove beaters from mixer before washing.

**SAVE THESE INSTRUCTIONS**



# HOW TO USE THE INDIVIDUAL ATTACHMENTS PROPERLY AND SAFELY

## MIXING AND KNEADING BOWLS



If light dough is to be kneaded or foam substance is to be beaten, set the beaters on the shaft of the mixing bowl. When creaming butter make sure that it is at room temperature. Heavy dough or hard butter can damage the beaters. For heavy dough use the kneading arm from start to finish.



The standard mixing bowl holds up to 8 lbs. of dough and up to 2 quarts of whipping cream can be whipped with the beaters.

To prevent spilling, place the cover ring on the bowl. The projections on the rim have to engage the pins on the edge of the bowl (bayonet lock), then turn the cover ring slightly in the direction shown. In order to melt butter and shortening, warm the mixing bowl by rinsing it with hot water or placing it into hot water. Never put it on an open flame a hot cooking plate or in a hot oven.

The mixing bowl is placed on the lower drive coupling of the drive unit and with slight pressure turned counterclockwise on to the base until it engages.

### Cleaning

Wash the mixing bowl, cover ring and kneading arm in soapy water. Pull out the beaters before washing. The Bowl is dishwasherproof.



Set the mixing bowl on **deluxe models** with a slight counterclockwise turn. Insert the kneading arm with a clockwise turn. Fasten the cover ring as described on page 12.

The stainless steel bowl holds up to 12 lbs. of dough.

Wash the bowl and kneading arm as usual. The fine gloss of the mixing bowl can be kept by polishing with non-abrasive polish. Rinse the cover ring in lukewarm water and dry immediately. It retains its gloss if it is not scratched.