

IMPORTANT SAFEGUARDS



FOR SLICER AND SHREDDER

In addition to the GENERAL SAFEGUARDS in the front of this book, the following SAFEGUARDS should be followed:

1. Read all instructions.
2. Avoid contacting moving parts. Never feed food by hand. Always use completely assembled slicer with feeder funnel and food pusher.
3. Blade is sharp. Handle carefully when cleaning.

SAVE THESE INSTRUCTIONS

SLICER & SHREDDER




First, set the drive disc onto the drive of the mixing bowl. Then set on the cutting insert. Finally, set on the cover ring and cover. **Without the cover with the feeder funnel, it is not possible to slice, shred, or grate!** The cover holds the cutting insert tight and protects the fingers from injury. Press it down hard and turn until it engages (bayonet lock), exactly like the cover ring. Always be sure that the covers engage all 3 bolts.

For the deluxe model slip the mounting shaft on the drive of the mixing bowl with a small clockwise turn, then the holder disc and finally the cutting insert. Set the cover on as described above.

Anything to be cut, shredded, or grated is to be fed through the feeder funnel. The most effective procedure with all cabbage varieties is as follows: Slice the head of cabbage lengthwise, then each half once or twice again and remove the heart so that it just fits into the feeder funnel. Roll some of the leaves so they can go through the feeder opening downwards.

Do not cut stale or hard bread.



Refill as long as the feeder is filled up $\frac{1}{2}$ "–1". Put in the heart last. Don't use force when pressing something through the feeder funnel. Push slightly with the pusher, but by no means push hard, as this does not improve the cutting power.

Cleaning

Slicing and grating inserts, drive disc and shaft (on deluxe model) can be washed and dried as usual.

Potato Shredding Disc

For the use of the potato shredding disc you need the cross-type drive. First place the cross-type drive on the mounting shaft. Then place the shredding disc on the drive in such a way that the four recesses on the edge of the disc lie on the arms of the drive. The insertion of the mounting shaft into the mixing bowl of the deluxe model is accomplished as with the slicer and shredder attachment, also the mode of operation.

Cleaning

Cleaning of the potato shredding disc is done in the same way as with the slicer and shredder.

