
IMPORTANT SAFEGUARDS


FOR CENTRIFUGAL JUICER

In addition to the GENERAL SAFEGUARDS in the front of this book, the following SAFEGUARDS should be followed:

1. Read all instructions.
2. Always make sure juicer cover is clamped securely in place before motor is turned on. Do not unfasten clamps while juicer is in operation.
3. Be sure to turn switch to "OFF" position after each use of your juicer. Make sure the motor stops completely before disassembling.
4. Do not put your fingers or other objects into the juicer opening while it is in operation. If food becomes lodged in opening, use food pusher or another piece of fruit or vegetable to push it down. When this method is not possible turn the motor off and disassemble juicer to remove the remaining food.

SAVE THESE INSTRUCTIONS

CENTRIFUGAL JUICER




The centrifugal juicer consists of several individual pieces. When assembling these pay attention to the correct sequence as illustrated.


Before extracting juice, wash fruit or vegetables thoroughly, and cut them into small pieces, if necessary, so that they can easily go through the filler opening. Place a container under the outlet and **switch on to Speed 1**. The pusher helps you with the refilling. According to the sort of fruit or vegetable, you can extract juice from 1-1³/₄ lbs. at a time.

When extracting large volume of juice, please note the following: Always switch the machine off as soon as the strainer basket is full; at the latest, when the speed of the centrifuge decreases noticeably. The strainer basket is emptied within seconds. As soon as the machine stops, loosen holding springs, remove cover, lift out strainer basket from the top (shredding disc remains in place), remove remains with a rubber scraper from the strainer basket and, if necessary, clean it under the tap. When removing remains always take care that the strainer basket is not scratched, and that it is not dented or otherwise damaged. The cleaned strainer basket is then replaced in the same way as described above. Note that the shredding

disc has teeth of different sizes on the front and rear. This gives you the advantage that not only hard but softer fruit and vegetables as well can be utilized. Please note also that the "fine" side is meant for the hard, the "coarse" side for the softer foods. Softer fruit or vegetables should not be crushed too finely, otherwise you obtain pulp but no juice.



First, place the driving disc on the drive and turn it until the disc engages.




Then place the shredding disc so that the flattened point of the opening in the middle lies exactly on the flattened point of the driving axle.




Then screw on the nut, holding the shredding disc with the other hand



The fixing nut on the shredding disc may be tightened or loosened with the reverse side of the pusher: The recess at its thicker end fits the nut exactly. Hold the shredding disc with one hand.



Now press the strainer basket with its four recesses downwards on the narrow stud of the driving disc until you hear the basket engage. If correctly placed, it is level with the top of the bowl.



Finally put on the cover and fasten it with the two holding springs – so that the spring with red marking grips over the housing strip with red marking.



The assembled appliance is mounted like the blender and engaged by turning it counterclockwise.



Place the juicer on the drive and turn it until it engages.



You only have to fasten the drain hose and the juicer is ready for work.

Cleaning

After operating, it is best to dismantle the attachment at once for easy cleaning. It is best to clean the individual parts immediately after use under the tap. **The bowl should never be immersed into water.**